

# HS-3510W G2/HS-3512W G2/HS-3514W G2 JUMPER SETTING

Ver. A1

- **JP1 : For CR open/close status port selection**  
 Pin 1-3 、 2-4 Short: For COM1  
 Pin 3-5 、 4-6 Short : For COM5
- **JP2 : LVDS Select Enable/Disable**  
 Pin 1-2 Short : LVDS Select Enable (For HS-3510W G2/ HS-3512W G2)  
 Pin 2-3 Short : LVDS Select Disable (For HS-3514W G2)
- **JCOM\_SEL1 : COM1/COM2 PORT DC SUPPLY SELECT**  
 Pin 1-3 Short : COM1 Pin1 connected as 12V DC  
 Pin 3-5 Short : COM1 Pin1 connected as DCD  
 Pin 2-4 Short : COM2 Pin1 connected as 12V DC  
 Pin 4-6 Short : COM2 Pin1 connected as DCD
- **JCOM\_SEL2 : COM3 PORT DC SUPPLY SELECT**  
 Pin 1-2 Short : COM3 Pin1 connected as 12V DC  
 Pin 2-3 Short : COM3 Pin1 connected as DCD
- **COM1~COM3 : +5V through BIOS ; VGA +12V through BIOS**  
 Press ESC to access Configuration\Super IO Configuration\OEM IO Configuration  
 VGA DSUB 12V : Disabled  
 COM1 DB9 5V : Disabled  
 COM2 DB9 5V : Disabled  
 COM3 DB9 5V : Disabled

- **SW1 : Clear CMOS Setting**

DIP	Switch select	
1 & 2	1: ON, 2: ON	Reserved
	1: ON, : OFF	Normal Operation
	1: OFF, 2: ON	Clear CMOS
	1: OFF, 2: OFF	Reserved
3	OFF	Reserved

